



WATCH DISPLAY	TIMESSETTING	TIME SETTING, CONT.	ALARM SETTINGS
 <p>A - START/STOP BUTTON B - RESET BUTTON C - REAL-TIME/MODE BUTTON D - BACKLIGHT BUTTON</p>	<p>This watch features hour, minute, second, month, date, day, alarm, and stopwatch displays.</p> <p>1. To set the Time and Date: Press the Real-Time/Mode Button (part C) three times. The display you are changing will blink. You can change the displays in the following sequence:</p> <ul style="list-style-type: none"> • Hour – Press the Reset Button (part B) once to select • Minute – Press the Reset Button (part B) twice to select • Month – Press the Reset Button (part B) three times to select • Day of the Week – Press the Reset Button (part B) four times to select • Date – Press the Reset Button (part B) five times to select • Second – Press the Reset Button (part B) six times to select 	<p>2. Press the Start/Stop Button (part A) to adjust each display.</p> <p>3. Once each display is adjusted, press the Real-Time/Mode Button (part C) to set.</p>	<p>TO SET THE ALARM</p> <p>1. Press the Real-Time/Mode Button (part C) two times.</p> <p>2. Press the Start/Stop Button (part A) to select the Alarm/Chime. Press the Reset Button (part B) to adjust the alarm hour, and press the Start/Stop Button (part A) to adjust the alarm minute.</p> <p>3. Press the Reset Button (part B) to set the alarm, and press the Real Time/Mode Button (part C) to return to the main screen.</p> <p>4. To turn the Alarm Off: Press the Reset Button (part C) to turn the alarm off and to turn on the snooze function. Press either the Start/Stop Button (part A) or the Reset Button (part B) to turn the snooze function off. The alarm will stop automatically after 20 seconds.</p>

ALARM SETTINGS, CONT.	STOPWATCH SETTINGS	FEATURES	Stauer® HERITAGE OF ART & SCIENCE Stauer Magnus Digital Watch INSTRUCTION MANUAL
<p>TO SET THE CHIME FUNCTION</p> <p>1. Chime Mode: To have your watch sound at every hour, press The Real-Time/Mode Button (part C) twice.</p> <p>2. Press the Start/Stop Button (part A) until “CH” appears to indicate Chime Mode.</p> <p>3. To turn Chime Mode off, press the Start/Stop Button (part A) until the “CH” disappears.</p>	<p>TO SET THE STOPWATCH</p> <p>1. Press the Real-Time/Mode Button (part C) once.</p> <p>2. Press the Start/Stop Button (part A) once to start timing, and press it twice to stop timing.</p> <p>3. To reset the stopwatch function, press the Reset Button (part B) once and then press the Real Time/Mode Button (part C) to return to the watch to normal operating function.</p>	<ul style="list-style-type: none"> - 1/100 chronograph with split function - Day, month, and date LCD display - Daily alarm with snooze function - Stainless steel back - Cotswold™ Mineral Crystal 	
<p>Visit us at www.stauer.com to learn more about the fantastic benefits of owning a Stauer Watch! www.stauer.com</p>			