


## WATCH DISPLAY



- A - CHRONOGRAPH SECONDS DIAL
- B - START/STOP CHRONO BUTTON
- C - CROWN
- D - 24 HOUR DIAL
- E - RESET CHRONO BUTTON
- F - DATE WINDOW
- G - WATCH SECONDS DIAL
- H - CHRONOGRAPH MINUTE DIAL

## TIMESSETTING

Locate the crown on your Stauer watch (see diagram part C). Please note the three crown positions (0-1-2) in part c of above diagram.

1. To set the time: Pull the crown out to position "2" (see diagram part C) which will allow you to position watch hands for proper time selection. Rotate the crown clockwise until the desired time is set.
2. When finished setting the time, push the crown back to the "0" (zero) position. The small second hand (dial part F) begins to run.

### SETTING THE DATE

1. Pull the crown out to the first position.
2. Turn the crown counter-clockwise to set the date (Part F).

- The date should not be adjusted between approximately 9pm and 01:00am.
- 3. After the date has been set, push the crown (part C) back to position "0" (zero).

### USING THE CHRONOGRAPH

This chronograph is able to measure and display time in 1/1 second united up to a maximum of 59 minutes (part H) 59 seconds (part G).

Measuring the time with the chronograph

1. The chronograph can be started and stopped each time button "B" is pressed.
2. Pressing button "E" resets the chronograph and the chronograph second hand (part A) and chronograph minute hand (part H) will return to the zero position.

### CHRONOGRAPH RESET (INCL. AFTER REPLACING BATTERY)

Chronograph Reset (includes after replacing the battery) This procedure should be performed when the chronograph second hand does not return to zero position after the chronograph has been reset and after the battery has been replaced.

1. Pull the crown out to position 2.
2. Press button "B" to set the chronograph second hand to the zero position. The chronograph hand can be advanced rapidly by continuously pressing button "B".
3. Once the hand has been set to the zero position, return the crown to the normal position.

## FEATURES

- Quartz Movement
- Genuine leather crocodile embossed band
- Chronograph
- Rose Gold-Fused Case

## IMPORTANT

Do not push the crown to the normal position while the chronograph second hand returns to the zero position. It stops on the way when the crown is returned to the normal position and its position is recognized as the zero position.

# Stauer

HERITAGE OF ART & SCIENCE

Stauer Flyboy 1916 Watch  
INSTRUCTION MANUAL



Visit us at, [www.stauer.com](http://www.stauer.com) to learn more about the fantastic benefits of owning a Stauer Watch! [www.stauer.com](http://www.stauer.com)

