


WATCH DISPLAY



A - Crown
B - Date Window

SETTINGS

This watch features hour, minute, and seconds hands, as well as a date window.

TO SET THE TIME

1. Pull the crown (part A) out to position "2" and rotate it to the desired time.
2. Once the correct time is set, push the crown back into "0" (zero) position.

TO SET THE DATE

1. Pull the crown (part A) out to position "1" and rotate it to the desired time.
2. Once the correct date is set, push the crown back into "0" (zero) position.

FEATURES

- Precision movement
- Stainless steel back
- Cotswold™ mineral crystal
- Date window
- Genuine leather strap
- Water resistant to 3 ATM

Stauer[®]
HERITAGE OF ART & SCIENCE

Stauer Timemaster Watch
INSTRUCTION MANUAL



Visit us at www.stauer.com
to learn more about the fantastic
benefits of owning a Stauer Watch!

www.stauer.com