# E. C. S.

- A Start/Stop Button
- B Crown
- C Reset Button
- D Digital Time
- E Real-Time/Mode Button
- F Backlight Button

# **TIMESETTING**

### TO SET THE TIME - ANALOG

- **1.** Pull the crown (part B) out to position "1" and rotate it to the desired time.
  - **2.** Once the correct time is set, push the crown back into "0" (zero) position.

### TO SET THE TIME – DIGITAL

- ${\bf 1.}\ {\rm Press}\ {\rm the}\ {\rm Real\text{-}Time/Mode}\ {\rm Button}\ ({\rm part}$
- E) three times to Time Setting mode. The seconds digits will blink. Select an item in the following sequence by pressing the Reset Button (part C):
- Hour Minute Month Date Day

  NOTE: When setting the hour, an "H" will
  flash with 24 hour format, and either an "A" or

  "P" (for a.m. or p.m.) with 12 hour format.
- **2.** Press the Start/Stop Button (part A) to adjust each selection above.
- **3.** Press the Real-Time/Mode Button (part E) to return to Real Time mode.

# USING THE ALARM

### TO SET THE DAILY ALARM/CHIME

- 1. Press the Real-Time/Mode Button (part E) two times to enter Alarm mode. Hour digit will blink.
- **2.** Press the Reset Button (part C) to select the hour or minute setting. Press the Start/Stop Button (part A) to adjust the flashing item.
- 3. Once the time has been set, press the Start/Stop Button (part A) to turn the alarm on
- **4.** To exit the alarm mode press the Real-Time/Mode Button (part E) watch will return to the real-time mode.
- **5.** To turn the alarm off, press the Start/Stop Button (part A).

# USING THE CHRONOGRAPH

### TO SET THE CHRONOGRAPH

- **1.** Press the Real-Time/Mode Button (part E) one time to enter Stopwatch mode.
- **2.** To start counting, press the Start/Stop Button (part A).
- **3.** To stop counting, press the Start/Stop Button (part A).
- **4.** Press the Reset Button (part C) to reset the stopwatch to "00."
- **5.** To record split times, press the Reset Button (part C) while the stopwatch is running to turn the split timer on/off.
- **6.** To exit the stopwatch mode press the Real-Time/Mode Button (part E) watch will return to the real-time mode.

# **FEATURES**

- Precision digital/analog hybrid movement
- Stainless steel case back
- Cotswold™ mineral crystal
- Water-resistant rubber with stainless steel band
- Chronograph function
- Digital hour, minute, second, date, month, and day of the week displays
- Hourly chime and daily alarm
- 12/24 hour option
- EL backlight
- Water resistant to 3 ATM



Stauer Sport Hybrid Chronograph Watch

INSTRUCTION MANUAL



Visit us at www.stauer.com to learn more about the fantastic benefits of owning a Stauer Watch!

www.stauer.com