WATCH DISPLAY **SETTINGS**

This watch features hour and minute hands, as well as a date window and a seconds dial.

TO SET THE TIME

- 1. Pull the crown (part A) out to position "2" and rotate it to the desired time.
- 2. Once the correct time is set, push the crown back into "0" (zero) position.

TO SET THE DATE

- 1. Pull the crown (part A) out to position "1" and rotate it to the desired time.
- 2. Once the correct date is set, push the crown back into "0" (zero) position.

FEATURES

- Precision movement

A - Crown B - Date Window

C - Seconds Dial

- Stainless steel caseback
- Luminous hands
- Second dial
- Date window
- Water resistant to 3 ATM

Stauer High Noon Watch INSTRUCTION MANUAL



Visit us at www.stauer.com to learn more about the fantastic benefits of owning a Stauer Watch!

www.stauer.com