


WATCH DISPLAY



- A - Minute Button
- B - Start/Stop Button
- C - Crown
- D - 24 Hour Dial
- E - Chronograph Reset Button

TIMESETTING

TO SET THE TIME

1. Pull the crown (part C) out to position "2" so that the second hand stops at (0) position.
2. Turn the crown to set the hour and minute hands.

USING THE CHRONOGRAPH

This chronograph is able to measure and display time in 1/1 second up to 1 hour.

Measuring time with the chronograph

1. The chronograph can be started and stopped each time the START/STOP button (part B) is pressed.
2. Pressing the RESET button (Part E) resets the chronograph and all hands return to their 0 positions.

CHRONOGRAPH RESET

CHRONOGRAPH RESET

This procedure should be performed when the chronograph second hand does not return to zero position after the chronograph has been reset and after the battery has been replaced.

1. Pull the crown out to the 2nd position.
2. Press the START/STOP button (Part B) to set the chronograph second hand to the 0 position.
3. The chronograph hands can be advanced rapidly by continuously pressing the START/STOP button (Part B).

CHRONOGRAPH RESET

4. Once the hands have been zeroed, reset the time and return the crown to its normal position.
- *Do not return crown to normal position while chronograph second hand return to 12:00 (ZERO) position.
Hand stops on the way when crown are returned to normal position and these positions are recognized as 12:00 (ZERO) position.

FEATURES

- Precision movement
- Chronograph function
- Stainless steel case & back
- Minute, Second Subdials
- Cotswold® crystal
- Genuine leather strap
- Water resistant to 3 ATM

Visit us at www.stauer.com
to learn more about the fantastic
benefits of owning a Stauer Watch!

www.stauer.com

Stauer®

Afford the Extraordinary.

Stauer Co-Pilot
Chronograph Watch

INSTRUCTION MANUAL

