


WATCH DISPLAY



- A - Date Dial
- B - Crown
- C - 24 Hour Dial with Sun/Moon Indicator
- D - Day of the Week Dial

TIMESSETTING

TO SET THE DATE

1. Pull the crown (part B) out to position "1."
2. Rotate the crown counter-clockwise (towards you) to advance the Date Dial (part A). Press crown (part B) back to position "0" to finish setting the time.

TO SET THE TIME AND DAY OF THE WEEK

1. Pull the crown (part B) out to position "2."
2. Rotate the crown clockwise (away from you) to advance the hour and minute hands, as well as the Day of the Week dial (part D). The Day of the Week can only be set by advancing the hour hand by 24 hours per day. *Always rotate your hour and minute hands in a clockwise direction to set the time. If you rotate the hands in a counter clockwise position, it may not always change the day correctly.
3. Press crown (part B) back to position "0" to finish setting the time.

FEATURES

- Precision movement
- Stainless steel crown & caseback
- Genuine leather band
- Date subdial at 3 o'clock
- Day of the week subdial at 9 o'clock
- 24-hour subdial with sun/moon indicator at 6 o'clock
- Water resistant to 3 ATM
- Fits wrists up to 8 1/2"

Visit us at www.stauer.com
to learn more about the fantastic
benefits of owning a Stauer Watch!

www.stauer.com

Stauer®

Afford the Extraordinary.

Stauer Canterbury Watch
INSTRUCTION MANUAL

