


WATCH DISPLAY



- A - Timesetting Button A
- B - Timesetting Button B
- C - Crown
- D - Dual Time Minute Subdial
- E - Dual Time Hour Subdial
- F - 24-hour Dial

TIMESSETTING

This watch features hour and minute hands, as well as a 24-hour subdial, 12-hour dual time hour and minute subdials.

TIMESSETTING THE MAIN DIAL:

1. Pull the crown (part C) out to position "1." Rotate the crown to adjust the watch hands to the desired time selection. Once the time is set, push the crown back into the original "0" position.

TIMESSETTING THE DUAL TIME HOUR SUBDIAL (part E):

1. While the crown (part C) is at position "0", push buttons A or B to adjust the hour dial (part E).

TIMESSETTING THE DUAL TIME MINUTE SUBDIAL (part D):

1. Pull crown (part C) out to position "1". Do not rotate the crown. Push buttons A & B to set the minute dial. Once set, push crown back into the original "0" position.

Stauer®

Afford the Extraordinary.

INSTRUCTION MANUAL

Visit us at www.stauer.com
to learn more about the fantastic
benefits of owning a Stauer Watch!
www.stauer.com

