

To Set The Time - Digital

1. Press the Digital-Time/Mode Button (part C) three times to Time Setting mode. The "second" digits will blink. Press Date/Start/Stop Button (part B) to reset the seconds to "00".
2. Select an item in the following sequence by pressing the Reset Button (part D): Minute-Hour-Date-Month-Day of the week-Second – use Date/Start/Stop Button (part B) to select the correct digits
3. Press the Digital-Time/Mode Button (part C) to return to the digital time display mode.

To Set the Daily Alarm/Chime

1. Press the Digital-Time/Mode Button (part C) two times to enter Alarm mode.
2. Press the Reset Button (part D) to select the hour or minute setting. Press the Date/Start/Stop Button (part B) to adjust the flashing item.
3. To exit the alarm mode press the Digital-Time/Mode Button (part C) – watch will return to digital time display mode.
4. To turn the alarm on/off, press the Date/Start/Stop Button (part B).

TO SET THE TIME – ANALOG

1. Pull the Crown (E) out and rotate it to the desired time.
2. Once the correct time is set, push the crown back into the case.

Stauer®

Afford the Extraordinary.


INSTRUCTION MANUAL




Stauer

Visit us at www.stauer.com to learn more about the fantastic benefits of owning a Stauer Watch!

Hybrid Watch Instruction



Product function mode



To Use Stopwatch Function

1. To enter Stopwatch mode, press Mode Button (part C) one time.
2. To start counting, press the Date/Start/Stop Button (part B).
3. To stop counting, press the Date/Start/Stop Button (part B).
4. Press the Reset Button (part D) to reset the stopwatch to "00."
5. To record split times, press the Reset Button (part D) while the stopwatch is running to turn the split timer on/off.
6. To exit the stopwatch mode press the Digital-Time Mode Button (part C) – watch will return to the digital time display mode.