

Stauer®

Afford the Extraordinary.

INSTRUCTION MANUAL

WATCH DISPLAY

TIMESSETTING


USING THE CHRONOGRAPH

TO SET THE CHRONOGRAPH

This chronograph is able to measure and display time in 1 second increments up to a maximum of 59 seconds (part E).

1. To start the Chronograph feature, press the Start/Stop Button (part A). To measure split times press the Reset Button (part D) to stop counting.

2. Press the Reset Button (part D) to reset the chronograph, the Chronograph Second Dial (part E) will all return to the zero position.



- A - Start/Stop Button
- B - Crown
- C - 24-Hour Dial
- D - Reset Button
- E - Chronograph Second Dial
- F - Second Hand

TO SET THE TIME

1. Pull the crown (part B) out to position "1" and rotate it to the desired time.

2. Once the correct time is set, push the crown back into "0" (zero) position. The Second Hand (part F) will start to run.

IMPORTANT

When resetting the chronograph, the second chronograph hand (part E) is in the "0" o'clock position.

NOTE:
The 24hr-dial (part C) syncs with the main dial time. For example, if the time is 8:00PM, then the 24 hour subdial will display 20 which essentially is 20:00 in 24 hour format. It allows user to identify AM/PM.

Visit us at www.stauer.com
to learn more about the fantastic
benefits of owning a Stauer Watch!
www.stauer.com