


WATCH DISPLAY



- A - Start/Stop Button
- B - Digital Time Display
- C - Crown
- D - Split/Reset Button
- E - Date
- F - Alarm
- G - Real-Time/Mode Button
- H - Backlight Button
- I - Day of the Week

TIMESSETTING

TO SET THE TIME – ANALOG

1. Pull the crown (part C) out to position “1” and rotate it clockwise to the desired time.
2. Once the correct time is set, push the crown back into “0” (zero) position.

TO SET THE TIME – DIGITAL

1. Press the Real-Time/Mode Button (part G) three times to Time Setting mode. The second portion of the Time display (part B) will blink. Select an item in the following sequence by pressing the Split/Reset Button (part D): Minute • Hour • Date • Month • Day
2. Press the Start/Stop Button (part A) to adjust each selection above.
3. Press the Real-Time/Mode Button (part G) to return to Real Time mode.

PLEASE NOTE:

When checking the Date (part E), dial will appear shaded over when date is displayed.

USING THE ALARM

TO SET THE DAILY ALARM/CHIME

1. Press the Real-Time/Mode Button (part G) two times to enter Alarm mode. Hour portion of the Digital Time Display (part B) will be flashing.
2. Press the Split/Reset Button (part D) to select the hour or minute setting. Press the Start/Stop button (part A) to adjust the flashing item.
3. Press the Split/Reset Button (part D) to stop sounding the alarm.
4. To exit the alarm mode press the Real-Time/Mode Button (part G) – watch will return to the real-time mode.
5. To turn the alarm off, press the Reset Button (part D) for two seconds and then press the Start/Stop Button (part A) to zero.

PLEASE NOTE:

You can use the two movements – digital and analog – to display different times zones.

USING THE CHRONOGRAPH

FEATURES

TO SET THE CHRONOGRAPH

The display range of the chronograph is 23 hours, 59 minutes and 59.99 seconds. The stopwatch is accurate to 1/100 second.

1. Press the Real-Time/Mode Button (part G) one time to enter Chronograph mode.
2. To start the Chronograph feature, press the Start/Stop Button (part A).
3. Once stopped, press the Split/Reset Button (part D) to reset to zero.
4. To record split times, press the Split/Reset Button (part D) while the Chrono is running to turn the split timer on/off.
5. To stop counting, press the Start/Stop Button (part A).
6. To reset (set to zero) the split time display press the Split/Reset Button (part D).
7. To exit the Chronograph mode press the Real-Time/Mode Button (part G) – watch will return to the real-time mode.

- Precision Digital/Analog Hybrid movement
- Stainless steel caseback and band
- LED subdials displaying day of the week, month, and date
- Dual time zone feature
- Stopwatch
- Alarm feature
- Water resistant to 3 ATM

Visit us at www.stauer.com to learn more about the fantastic benefits of owning a Stauer Watch!

www.stauer.com

Stauer®

HERITAGE OF ART & SCIENCE

Men's Due
Volta Watch

INSTRUCTION MANUAL

