


WATCH DISPLAY



- A - Start/Stop Button
- B - Crown
- C - Split/Reset Button
- D - Date Window
- E - Chronograph Second Dial
- F - Chronograph Minute Dial
- G - 24 Hour Military Time Dial

TIMESSETTING

SETTING THE DATE

1. Pull the crown (part B) out to position "1" and turn the clockwise (away from you) to set the desired date.
2. Push the crown back to position "0".

NOTE: The date should not be adjusted between 9:00pm to 1:00am, otherwise the day may not change properly.

SETTING THE TIME

1. Pull the crown (part B) out to position "2" when the second hand is at the twelve o'clock position. Turn the crown counter clockwise (towards you) to set the desired time.
2. Push the crown back to position "0".

USING THE CHRONOGRAPH

This is a 60 second chronograph.

1. To START the Chronograph press the Start/Stop button (part A).
2. To STOP the Chronograph press the Start/Stop button (part A) again.
3. To RESET (set to zero) the Chronograph pull the crown (part B) out to position "2". Press the Split/Reset button (part C). Push the crown back to position "0".

This procedure should be performed when the chronograph second hand does not return to zero position after the chronograph has been reset and after the battery has been replaced.

Stauer®

Afford the Extraordinary.

Stauer Incan Treasure
Chronograph Watch

INSTRUCTION MANUAL



Visit us at www.stauer.com
to learn more about the fantastic
benefits of owning a Stauer Watch!

www.stauer.com