


WATCH DISPLAY

TIMESSETTING

This watch features minute, second, and hour hands, as well as a date window.



A - Date Window

B - Crown

1. To Set the Time: Pull the crown (part B) out to position “2” and turn the hands to select the correct time. Once time is set, push crown back into the original “0” (zero) position.

2. To Set the Date: Pull the crown (part B) to position “1.” Turn the crown clockwise until the date dial (part A) reads proper date selection. Once date is set, push the crown back into the original “0” (zero) position.

FEATURES

- Precise Swiss movement
- Date window
- Water resistant to 3 ATM
- Made in Switzerland

Stauer[®]
Afford the Extraordinary.

INSTRUCTION MANUAL

Visit us at www.stauer.com
to learn more about the fantastic
benefits of owning a Stauer Watch!

www.stauer.com

