


## WATCH DISPLAY



- A - Start/Stop Button
- B - Crown
- C - Date Window
- D - Split/Reset Button
- E - Chronograph Minute Hand
- F - Hour Hand
- G - 1/5 Second Chronograph Hand
- H - Minute Hand

## TIMESSETTING

Locate the crown on your Stauer watch (part B) and please note the three crown positions (0-1-2).

### TO SET THE TIME

1. Pull the crown (part B) out to position "2" and rotate it to the desired time.
2. Once the correct time is set, push the crown back into "0" (zero) position.

### TO SET THE DATE

1. Pull the crown (part B) out to position "1" and rotate it clockwise to the desired date.
2. Once the correct date is set, push the crown back into "0" (zero) position.

**NOTE:** The date should not be adjusted between 9:00pm to 1:00am; otherwise, the day may not change properly.

## USING THE CHRONOGRAPH

This chronograph measures and displays time in one second increments up to a maximum of 59 minutes 59 seconds.

1. To START the Chronograph press the Start/Stop button (part A).
2. To STOP the Chronograph press the Start/Stop button (part A) again.
3. To RESET (set to zero) the Chronograph press the Split/Reset button (part D).

**NOTE:** when the chronograph second hand does not return to zero position after the chronograph has been reset and after the battery has been replaced. Please Follow "CHRONOGRAPH RESET" to reset the hand.

## CHRONOGRAPH RESET

1. Pull the crown (part B) out to position "2".
2. Press the Start/Stop button (part A) for two seconds. The Chronograph Minute Hand (part E) will return to the "0" position. The chronograph minute hand can be advanced rapidly by continuously pressing the Split/Reset Button (part D) or slowly by intermittently pressing the Start/Stop button.
3. Press the Start/Stop button (part A) to reset the Chronograph Second Hand (part G) to the "0" position. The chronograph second hand can be advanced rapidly by continuously pressing the Split/Reset Button (part D) or slowly by intermittently pressing the Start/Stop button.
4. Once the hand has been set to "0" position, return the crown to the normal "0" position.

## NOTE

The chronograph can measure up to 60 minutes in 1/5 second increments, capable of timing 12 hours. When the measurement reaches 12 hours, the chronograph automatically stops counting.

Visit us at [www.stauer.com](http://www.stauer.com)  
to learn more about the fantastic  
benefits of owning a Stauer Watch!  
**[www.stauer.com](http://www.stauer.com)**

**Stauer**<sup>®</sup>  
HERITAGE OF ART & SCIENCE

INSTRUCTION MANUAL

