CAMO DESERT EMERGENCY SURVIVAL KIT #57313

The Kit contains:

- Bracelet Watch: Time Display + Compass + Whistle + Fire Starter + Paracord Rope + Thermometer*.
 The watch is powered by a SR626SW battery (included).
- Multi-tool: Small knife, can opener, pliers, a mini Philips head screwdriver, and a carabiner-style clip.
- Multi-function Card: Rulers, small rope, can opener, bottle opener, serrated edge, and screwdrivers.
- Flashlight: with 3 different settings. Takes AA batteries (not included).
- Emergency Blanket: 130cm x 210cm.
- Camouflage Bag: 17.5cm x 8.5cm x 11cm.



To adjust time:

- 1. Pull the crown out.
- 2. Turn the crown clockwise to set the hands to the desired time.
- Once the correct time is displayed, firmly press the crown back into its original position.
- * The watch displays the hour, minute, and second hands.
 The subdials and push buttons are for aesthetic purposes only.
- ** The thermometer displays temperatures in Celsius (°C). Fahrenheit (°F) = °C × (9/5) + 32.

NOTE: The subdials and the push buttons on the bezel are not functional, they are for decoration only. It is important to use it with caution. Always wear safety glasses when using the knife or cutting tool. Do not use the tools for any purpose other than their intended use.

If you have any questions, please contact Stauer customer service at 1-888-333-2012.

California residents WARNING: This product can expose you to chemicals, including Chromium, Nickel, and/or Lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.