


WATCH DISPLAY



A - Crown
B - Date Window

TIME SETTING

This watch features hour, minute, and seconds hands, as well as a date window.

TO SET THE TIME

1. Pull the crown (part A) out to position "2" and rotate it to the desired time.
2. Once the correct time is set, push the crown back into "0" (zero) position.

TO SET THE DATE

1. Pull the crown (part A) out to position "1" and rotate it to the desired date.
2. Once the correct date is set, push the crown back into "0" (zero) position.

FEATURES

- Made in Switzerland with precision Swiss Ronda 515 movement
- Stainless steel caseback
- Leather band in brown
- Case diameter: 44mm
- Date window at 3 o'clock position
- Water resistant to 3ATM
- Fits wrists up to 8 1/4"
- 22mm Band width
- Case 9mm thick
- Battery type 371

Visit us at www.stauer.com
to learn more about the fantastic
benefits of owning a Stauer Watch!

www.stauer.com

Stauer®

Afford the Extraordinary.

Stauer Swiss
Tactical Watch

INSTRUCTION MANUAL



SAFETY GUIDE

1. The battery is only replaced at a professional service center, and consumers are not allowed to replace the battery themselves.
2. Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. DO NOT dispose of batteries in household trash or incinerate.
3. Even used batteries may cause severe injury or death.
4. Call a local poison control center for treatment information.
5. Battery type 371
6. Nominal voltage: 1.55V
7. Non-rechargeable batteries are not to be recharged.
8. Do not force discharge, recharge, disassemble. Cannot be heated or incinerated. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
9. Ensure the batteries are installed correctly according to polarity (+ and -).
10. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
11. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
12. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH OF CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

