
## WATCH DISPLAY




**A - Crown**
**B - Date Dial**
**C - Phase Moon Dial**
**D - Week Dial**

## SETTINGS

**TO SET THE WEEK AND TIME**
1. Pull the crown (part A) out to position "2" and turn the crown clockwise to set the week.
2. After setting the week, turn the crown clockwise to set the time.
3. Push the crown back to position "0".

**TO SET THE MOON PHASE**
1. Pull the crown (part A) out to position "1"
2. Turn the crown clockwise to change the phase of the moon.
3. Push the crown back to position "0".

**TO SET THE DATE**
1. Pull the crown (part A) out to position "1"
2. Turn the crown counterclockwise to set the date.
3. Push the crown back to position "0".

**NOTE:** Please do not turn the crown counterclockwise to set the week

Visit us at www.stauer.com
to learn more about the fantastic benefits of owning a Stauer Watch!
**www.stauer.com**

# Stauer®

Afford the Extraordinary

INSTRUCTION MANUAL

Authentic Stauer Historical Reproductions

## SAFETY GUIDE

# WARNING

1. The battery is only replaced at a professional service center, and consumers are not allowed to replace the battery themselves.
2. Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. DO NOT dispose of batteries in household trash or incinerate.
3. Even used batteries may cause severe injury or death.
4. Call a local poison control center for treatment information.
5. Battery type: SR621SW
6. Nominal voltage: 1.55V
7. Non-rechargeable batteries are not to be recharged.
8. Do not force discharge, recharge, disassemble. Cannot be heated or incinerated. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
9. Ensure the batteries are installed correctly according to polarity (+ and -).
10. Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
11. Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
12. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

## ⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours.**
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.

