


WATCH DISPLAY



- A - Chronograph Start/Stop Button
- B - Day of Week and Alarm/Chime Indicator
- C - Crown
- D - Reset Button
- E - Digital Seconds Display
- F - Mode Button
- G - Digital Hour/Minute Display
- H - Light Button

SETTING ANALOG and DIGITAL DISPLAYS

The **DIGITAL Day Display (part B)** shows the Day of the Week (SU, MO, TU, WE, TH, FR, SA).

The **DIGITAL Hour/Minute Dial (part G)** and **DIGITAL Seconds Display (part E)** show the hours, minutes and seconds.

The **ANALOG Display** shows the hours, minutes and seconds.

TO SET THE ANALOG TIME

1. Pull the crown (part C) out to position "1" and turn it clockwise or counterclockwise to set the time.
2. Once the correct time is set, push the crown back into original "0" (zero) position.

TO SET THE DIGITAL DISPLAYS

1. Press the "F" (Mode) Button 3 times to enter the digital time-setting mode – the seconds display will flash.
2. **To set the Minutes** press the "D" button, then tap the "A" button to select the min-

utes. Once they are correct, tap the "D" button to display the Hours - it will flash.

3. **To set the Hour** tap the "A" button to select the correct hour. ("A" for AM, "P" for PM or military time). Once the hour is correct, tap the "D" button to display the Date – it will flash.
4. **To set the Date** tap the "A" button. Once the correct Date is set, tap the "D" button to display the Month – it will flash. NOTE: To view the current date while in real-time mode, press and hold the "A" button and the date will appear in the "G" digital display.
5. **To set the Month** tap the "A" button. Once the Month is set, tap the "D" button to display the Day of the Week - it will flash.
6. **To set the Day of the Week Display (part B)** tap the "A" button. Once it is correct, tap the "D" button to display the seconds - they will flash.
7. **To reset the Seconds Display** tap the "A" button. Once they are reset, press the "F"

button to exit the setting mode and return to the real time display.

TO SET THE DAILY ALARM/CHIME

1. Press the "F" (Mode) Button 2 times to enter the Daily Alarm/Chime-setting mode.
2. **To set the Daily Alarm Hour** tap the "A" button to select the hour - the PM hours are noted with a small "P" in the upper left of the display window. Once the hour is selected press the "D" button once to display the minutes – they will flash.
3. **To set the Alarm Minutes** tap "A" to select the minutes. Once the minutes are set press the "F" button to return to real-time mode.
4. **To turn the Alarm On/Off:** After setting the alarm and returning to real-time mode, press BOTH "A" and "D" buttons simultaneously. When the Alarm/Chime is on you will see a small bell symbol in the center of the Day of the Week and Alarm/Chime Indicator dial (part B).



Alarm On Symbol

Operating the Chronograph

The display range of the chronograph is **23 hours, 59 minutes and 59.99 seconds.**

1. Press the "F" button once to enter the Chronograph function.
2. To **START** the Chrono tap the "A" button.
3. To **STOP** the Chrono tap the "A" button again.
4. To **RESET** (set to zero) the Chrono press the "D" button.
5. To **Record Split Times** press the "D" button while the Chrono is running to turn the split timer on and off.
6. To **EXIT** the split time mode press the "A" button and then press "D" to display the total of the combined split times.
6. To **RESET** (set to zero) the split time display press the "D" button.
6. To **EXIT** the Chronograph mode press the "F" button - watch will return to the real-time mode.

FEATURES

- Fits wrists 6¾" to 9"
- Quartz movement

Visit us at, www.stauer.com to learn more about the fantastic benefits of owning a Stauer Watch
www.stauer.com

Stauer®

HERITAGE OF ART & SCIENCE

Stauer Colossus
Hybrid Chronograph
INSTRUCTION MANUAL

